

W & H Peacock Catalogue 03 Jul 2018

- | | | | |
|-----|---|-----|--|
| *1 | KG39VL35GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *29 | KIR81AF30GB Bosch Built-in larder fridge |
| *2 | KG39VL35GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *30 | G4344X7GB-B Neff Built-under upright freezer |
| *3 | KG39VL35GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *31 | B57CR22N0BB Neff Oven |
| *4 | KG34NVI35GB Siemens LED light Hyper fresh Free-standing fridge-freezer | *32 | B47CR32N0BB Neff Oven |
| *5 | KG33XW30GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *33 | B57CS24N0BB Neff Oven |
| *6 | KG34NVW3AGB Siemens LED light Free-standing fridge-freezer | *34 | B57CR22N0BB Neff Oven |
| *7 | KG33NW20GB Bosch Free-standing fridge-freezer | *35 | B57VS24N0BB Neff Oven |
| *8 | KG34NW3AGB Bosch Free-standing fridge-freezer | *36 | HGB6764S6BB Bosch Oven |
| *9 | KG36XI35GB Bosch Vita Fresh LED light Free-standing fridge-freezer | *37 | B47CR32N0BB Neff Oven |
| *10 | KG36NAB35GB Siemens LED spot light Hyper fresh Free-standing fridge-freezer | *38 | B47CS34N0BB Neff Oven |
| *11 | KG34NW3AGB Bosch Free-standing fridge-freezer | *39 | HM656GNS6BB Siemens Oven with microwave |
| *12 | KG36VI30GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *40 | HRG6769S6BB Bosch Oven |
| *13 | KG39VW32GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *41 | HGB674BS1BB Bosch Oven |
| *14 | KG39VW35GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *42 | C27MS22N0BB Neff Compact oven with microwave |
| *15 | KG34NW3AGB Bosch Free-standing fridge-freezer | *43 | CMG633BB1BB Bosch Compact oven with microwave |
| *16 | KG34NW3AGB Bosch Free-standing fridge-freezer | *44 | B57CS24N0BB Neff Oven |
| *17 | KG34NW3AGB Bosch Free-standing fridge-freezer | *45 | B27CR22N1BB Neff Oven |
| *18 | KG33VL31GB Bosch LED light Vita Fresh Free-standing fridge-freezer | *46 | HBN331E4B-B Bosch Oven |
| *19 | KIV87VF30GB Bosch Built-in fridge-freezer combination | *47 | B27CR22N1BB Neff Oven |
| *20 | KI82LVS30GB Siemens Built-in larder fridge | *48 | C17MR02N0BB Neff Compact oven with microwave |
| *21 | KI1413F30GB Neff Built-in larder fridge | *49 | HB656GBS6BB Siemens Oven |
| *22 | KI81RVS30GB Siemens Built-in larder fridge | *50 | HGB634BS1BB Bosch Oven |
| *23 | KI81RVS30GB Siemens Built-in larder fridge | *51 | HGB634BS1BB Bosch Oven |
| *24 | KI87SAF30GB Siemens Built-in fridge-freezer combination | *52 | HGB634BS1BB Bosch Oven |
| *25 | KI85NAD30GB Siemens Integrated fridge/freezer | *53 | B44M42N5GBB Neff Oven |
| *26 | KI1813F30GB Neff Built-in larder fridge | *54 | B47CR32N0BB Neff Oven |
| *27 | KIV38X22GBB Bosch Built-in automatic fridge-freezer | *55 | B17CR32N1BB Neff Oven |
| *28 | KIV32X23GBB Bosch Built-in automatic fridge-freezer | *56 | N17HH20N0BB Neff Warming drawer |
| | | *57 | U17M42N5GBB Neff Double compact oven |
| | | *58 | U14M42N5GBB Neff Double oven |
| | | *59 | U17M42N5GBB Neff Double compact oven |
| | | *60 | WAQ284S0GBB Bosch Vario Perfect Eco Silence Drive Washing machine |
| | | *61 | W544BX0GB-B Neff Washing machine |
| | | *62 | WAT2840SGBB Bosch Serie 6 Vario Perfect Quiet Mark Eco Silence Drive Washing machine |
| | | *63 | WIW28300GBB Bosch Quiet Mark Eco Silence drive Washing machine |
| | | *64 | WAN28280GBB Bosch Serie 4 Eco Silence Drive Vario Perfect Washing machine |
| | | *65 | WAT28450GBB Bosch Serie 6 Quiet Mark Eco Silence Drive Washing machine |
| | | *66 | WAE28262GBB Bosch Washing machine |
| | | *67 | WAN28201GBB Bosch Vario Perfect Eco Silence Drive Serie 4 Washing machine |

- *68 WAW285H0GBB Bosch Serie 8 Quiet Mark Wifi Washing machine
- *69 WI14W500GBB Siemens iQdrive iSensoric Washing machine
- *70 WAT2840SGBB Bosch Serie 6 Vario Perfect Eco Silence Drive Quiet Mark Washing machine
- *71 WAN28100GBB Bosch Vario Perfect Serie 4 Eco Silence Drive Washing machine
- *72 WIW28300GBB Bosch Quiet Mark Eco Silence Drive Washing machine
- *73 WD14H421GBB Siemens Vario Perfect iQdrive iQ500 Washer-dryer
- *74 WAN28280GBB Bosch Serie 4 Vario Perfect Eco Silence Drive Washing machine
- *75 WIW28300GBB Bosch Quiet Mark Eco Silenece Drive Washing machine
- *76 WAN28201GBB Bosch Serie 4 Vario Perfect Eco Silence Drive Washing machine
- *77 WKD28541GBB Bosch Washer-dryer
- *78 WTN83200GBB Bosch Serie 4 Tumble dryer
- *79 WTWH7660GBB Bosch Serie 6 self cleaning condenser Tumble dryer
- *80 WTH85200GBB Bosch Heat pump technology Serie 4 Tumble dryer
- *81 WTN85280GBB Bosch Serie 4 Tumble dryer
- *82 SMS67MW00GB Bosch Serie 2 Perfect dry Free-standing dishwasher
- *83 SMS25EB00GB Bosch Serie 2 Silence Plus Free-standing dishwasher
- *84 SMS46IW04GB Bosch Serie 4 Silence Plus Free-standing dishwasher
- *85 SMS25AI00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm s.inox
- *86 S511A50X0GB Neff Dishwasher fully integrated 60 cm
- *87 S51M66X0GBB Neff Dishwasher fully integrated
- *88 SN636X00KGB Siemens Dishwasher fully integrated 60cm
- *89 SMV24AX01GB Bosch Dishwasher fully integrated 60cm
- *90 SMV24AX01GB Bosch Dishwasher fully integrated 60cm
- *91 SMV46IX00GB Bosch Dishwasher fully integrated
- *92 SN66D000GBB Siemens Dishwasher fully integrated 60cm
- *93 SMI50C12GBB Bosch Dishwasher integrated 60 cm white
- *94 SMV68MD02GB Bosch Dishwasher fully integrated
- *95 SMV46MX00GB Bosch Dishwasher fully integrated
- *96 KGN36IJ3AGB Bosch LED light Vita Fresh Free-standing fridge-freezer
- *97 KG36NXX3AGB Siemens LED light Hyper Fresh Free-standing fridge-freezer
- *98 GSN33VW30GB Bosch Free-standing upright freezer
- *99 KGN39VL35GB Bosch LED light Vita Fresh Free-standing fridge-freezer
- *100 KGN39VL35GB Bosch LED light Vita Fresh Free-standing fridge-freezer
- *101 KA92DAI20GB Siemens Hyper Fresh Anti finger print Side-by-side fridge-freezer
- *102 KGN34NW3AGB Bosch Free-standing fridge-freezer
- *103 KGE49BI30GB Bosch LED light Vita Fresh Free-standing fridge-freezer
- *104 GI7813E30GB Neff Built-in upright freezer
- *105 KI87VVS30GB Siemens Built-in fridge-freezer combination
- *106 KI5852S30GB Neff Built-in fridge-freezer combination
- *107 KIL42VS30GB Bosch Built-in larder fridge
- *108 KI1812S30GB Neff Built-in larder fridge
- *109 WAQ2836SGBB Bosch Vario Perfect Eco Silence Drive Washing machine
- *110 WAE24262GBB Bosch Washing machine
- *111 WTW85260GBB Bosch Self Cleansing Condenser Tumble dryer
- *112 WT45N200GBB Siemens iQ300 ISensoric Tumble dryer
- *113 WTW85470GBB Bosch Serie 6 Self Cleansing Condenser Tumble dryer
- *114 WTW87560GBB Bosch Serie 8 Self Cleansing Condenser Tumble dryer
- *115 WTN85280GBB Bosch Serie 4 Tumble dryer
- *116 WTN83200GBB Bosch Serie 4 Tumble dryer
- *117 WTE84106GBB Bosch Classixx 7 Tumble dryer
- *118 WT46W491GBB Siemens Extra Klasse iSensoric Tumble dryer
- *119 WTYH6790GBB Bosch Wifi Serie 8 Self Cleansing Condenser Tumble dryer
- *120 WTW85451GBB Bosch Serie 6 Self Cleansing Condenser Tumble dryer
- *121 WTW863S1GBB Bosch Self Cleansing Condenser Tumble dryer
- *122 WTM85250GBB Bosch Serie 4 Self Cleansing Condenser Tumble dryer
- *123 WTH83000GBB Bosch Tumble dryer
- *124 WTA79200GBB Bosch Serie 4 Tumble dryer
- *125 WT46W490GBB Siemens Extra Klasse iSensoric Tumble dryer
- *126 WTN83200GBB Bosch Serie 4 Tumble dryer
- *127 WTN83200GBB Bosch Serie 4 Tumble dryer
- *128 WTN85280GBB Bosch Serie 4 Tumble dryer

- *129 WT46G491GBB Siemens Extra Klasse iSensonicTumble dryer
- *130 WTE84106GBB Bosch Classixx 7 Tumble dryer
- *131 WTB84200GBB Bosch Tumble dryer
- *132 WTE84106GBB Bosch Classixx 7 Tumble dryer
- *133 WTE84106GBB Bosch Classixx 7 Tumble dryer
- *134 WTN83200GB Bosch Serie 4 Tumble dryer
- *135 WAT24421GBB Bosch Vario Perfect Eco Silence Drive Serie 6 Washing machine
- *136 WAB24161GBB Bosch Maxx 6 Washing machine SIWAMAT
- *137 W VH28422GBB Bosch Serie 6 Washer-dryer
- *138 WM14T690GBB Siemens Extra Klasse Intelligent Dosing system iSensonic Washing machine
- *139 WAN28280GBB Bosch Serie 4 Vario Perfect Eco Silence Drive Washing machine
- *140 WAW28560GBB Bosch Serie 8 Vario Perfect Quiet Mark Washing machine
- *141 WAB24161GBB Bosch Maxx 6 Washing machine SIWAMAT
- *142 SMS67MW00GB Bosch Serie 6 Perfect Dry Free-standing dishwasher
- *143 SMS25AW00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm white
- *144 SMS25EB00GB Bosch Serie 2 Silence Plus Free-standing dishwasher
- *145 SMS25EI00GB Bosch Serie 2 Silence Plus Freestanding dishwasher 60cm silver-inox
- *146 SMS25EB00GB Bosch Serie 2 Silence Plus free standing dishwasher
- *147 SMS46IW01GB Bosch Serie 4 Silence Plus Free-standing dishwasher white
- *148 SMS46IW04GB Bosch Serie 4 Silence Plus Free-standing dishwasher
- *149 SMS25AW00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm white
- *150 SMS46IW02GB Bosch Serie 4 Silence Plus Free-standing dishwasher white
- *151 SMS461100G Bosch silence plus Serie 4 dishwasher
- *152 SMS67MW00GB Bosch Serie 6 Perfect Dry Free-standing dishwasher
- *153 SMS24AW01GB Bosch Serie 2 Free-standing dishwasher 60cm white
- *154 SMS25EI00GB Bosch Serie 2 Silence Plus Freestanding dishwasher 60cm silver-inox
- *155 SMS53M08UKB Bosch Serie 6 Free-standing dishwasher Silver Inox
- *156 SMS25AW00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm white
- *157 SMS25EW00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm white
- *158 SMS46IW04GB Bosch Serie 4 Silence Plus Free-standing dishwasher
- *159 SMS46IW01GB Bosch Serie 4 Silence Plus Free-standing dishwasher white
- *160 SMS25AW00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm white
- *161 SMS25AI00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm s.inox
- *162 SMS40T32UKB Bosch Free-standing dishwasher 60 cm white
- *163 SMS25AW00GB Bosch Serie 2 Silence Plus Free-standing dishwasher 60 cm white
- *164 SN26M880GBB Siemens Free-standing dishwasher silver inox
- *165 SMS40T32UKB Bosch Free-standing dishwasher 60 cm white
- *166 SMS46IW01GB Bosch Serie 4 Silence Plus Free-standing dishwasher
- *167 SMI50C15GBB Bosch Dishwasher integrated stainless steel
- *168 SMV40C30GBB Bosch Dishwasher fully integrated 60cm
- *169 SMV40C30GBB Bosch Dishwasher fully integrated 60cm
- *170 SMV68MD01GB Bosch Super Silence plus Dishwasher fully integrated
- *171 S513M60X1GB Neff Dishwasher fully integrated
- *172 SMV40C30GBB Bosch Dishwasher fully integrated 60cm
- *173 S517T80D0GB Neff Dishwasher fully integrated
- *174 SMV24AX01G Bosch dishwasher
- *175 SMV50C10GBB Bosch Dishwasher fully integrated
- *176 B44S53N5GBB Neff Oven
- *177 B15CR32N1BB Neff Oven
- *178 B14M42N5GBB Neff Oven
- *179 B47CS34N0BB Neff Oven
- *180 HBN331E3B-B Bosch Oven
- *181 HBA23B150BB Bosch Oven
- *182 HBN331E4B-B Bosch Oven
- *183 U17S32N5GBB Neff Double compact oven
- *184 B47CR32NOV Neff Oven
- *185 U17M42N5GBB Neff Double compact oven
- *186 U14S32N5GBB Neff Double oven
- *187 B47CS34N0BB Neff Oven
- *188 GUD15A50GBB Bosch Built-under upright freezer
- *189 KU15RA51GBB Siemens Built-under larder fridge
- *190 HMT72G450BB Bosch Microwave oven
- *191 HMT72M450BB Bosch Microwave oven
- *192 HMT84M451BB Bosch Microwave oven
- *193 HMT72M450BB Bosch Microwave oven

- *194 HF24M564B-B Siemens Built-in microwave oven
- *195 H53W50N3GBB Neff Microwave
- *196 T48FD23X0-B Neff Induction hob, autarkic
- *197 PKE611CA1EB Bosch Electric hob, autarkic
- *198 EX851FVC1EB Siemens Induction hob, autarkic
- *199 T48FD23X0-B Neff Induction hob, autarkic
- *200 PKE611D17E Bosch electric hob
- *201 T46FD53X0-B Neff Induction hob, autarkic
- *202 EH601FEB1EB Siemens Induction hob, autarkic
- *203 ET651HE17EB Siemens Electric hob, autarkic
- *204 PUE611BF1BB Bosch Induction hob, autarkic
- *205 EU631FEB1EB Siemens Induction hob, autarkic
- *206 T59FT50X0-B Neff Induction hob, autarkic
- *207 DUL63CC50BB Bosch Built-under cooker hood
- *208 D66SH52N0BB Neff Chimney hood
- *209 EX875LX34EB Siemens Induction hob with extractor, autarkic
- *210 EX875LX34EB Siemens Induction hob with extractor, autarkic
- *211 EX875LX34EB Siemens Induction hob with extractor, autarkic
- *212 D95IHM1S0BB Neff Inclined hood
- *213 N17HH10N0BB Neff Warming drawer
- *214 C17FS32N0BB Neff Compact steam oven